

CRISTALLO hinge



Web code
DQDN1A

Planning

Hinge dimensions and gap calculation based on factory setting (mounting plate spacing = 0 mm)



Hinge and front protrusion at full opening angle

Overlay application





- A Cabinet front edge to centre of mounting plate drilling
20 mm with mounting plate A20
37 mm with mounting plate A37
- FA Front overlay

Dual application



- A Cabinet front edge to centre of mounting plate drilling
20 mm with mounting plate A20
37 mm with mounting plate A37
- FA Front overlay

Inset application



- A Cabinet front edge to centre of mounting plate drilling
21.5 mm + front thickness FD with mounting plate A20
38.5 mm + front thickness FD with mounting plate A37


Distance

MD	Front overlay FA (mm)																	
	-3.5	-3	-2.5	-2	-1.5	-1	2.5	4	5.5	7	8.5	10	11.5	13	14.5	16	17.5	19
0	0	0.5	1	1.5	2	2.5	6	7.5	9	10.5	12	13.5	15	16.5	18	19.5	21	22.5
3	3	3.5	4	4.5	5	5.5	9	10.5	12	13.5	15	16.5	18	19.5	21	22.5		
6	6	6.5	7	7.5	8	8.5	12	13.5	15	16.5	18	19.5	21	22.5				
9	9	9.5	10	10.5	11	11.5	15	16.5	18	19.5	21	22.5						

MD Mounting plate spacing (mm)

Due to the risk of breakage to glass and mirror doors, sufficient surrounding gaps are required (recommendation: min 2 mm)


Distance



- FA Front overlay
- KT Adhesion plate distance
 $KT = FA + 3.5 \text{ mm} + MD$
- MD Mounting plate spacing

KT Adhesion plate distance

Adjustment



Note

Please contact your glass or front suppliers concerning the right adhesive and its use in fixing the mounting | adhesion plate on to glass and mirrors.

Reference pages

Overview – CLIP top BLUMOTION CLIP top – hinges	71
Mounting plates	144
Accessories – hinge arm cover cap	151
Accessories – general	153
Overview – TIP-ON for doors	171
Overview – assembly devices	591
More technical details	698

Assembly, removal and adjustment

Short URL
www.blum.com/a210